

PANDORA'S
BOX CLASS

ULTRA FIREPOWER

SHOOTING GAME 3 IN 1

User Manual

Enjoy Life With Quality



一、 Select Game Menu :




PIC 1

二、 Motherboard interface



PIC 2

三、IO board and gun shocking interface definition (PIC 3)



PIC 3

四、Game setting introduction:

Press the setting button, then you can see the **setting menu** interface, please view Pic 4 for information



PIC 4

* Use 1P start button to move the cursor and choose the item you need, press 1P's trigger to make selection or change under the **setting menu** interface.

Total Coin Record : This item use to record the total coin insert into this machine, unable to reset.

TEST & CALIBRATE : Press 1P's trigger to enter, then you can see the **TEST & CALIBRATE** interface as pic 5




PIC 5

*1P Gun Calibrate(Move the cursor to this subject then press the trigger to enter 1P gun Calibrate menu)

* 2P Gun Calibrate(Move the cursor to this subject then press the trigger to enter 2P gun Calibrate menu)

* Back

Gun Calibrate: (1P's Calibrate for example) as (pic 5)



PIC 6

Please gunpoint 1 cross left corner, and then press the trigger (pic 7)



PIC 7

Please gunpoint 1 cross right corner, and then press the trigger (pic 8)



PIC 8

The gun mark will show on the screen, please complete press P1 trigger calibration . Please press the trigger again to return to the **TEST & CALIBRATE** interface, choose **BACK** return to **SETTING Menu** interface, saved the setting and exit, calibration is complete. The calibration of 2P is same as 1P.

Game Setting : (PIC 9)

- * Credit(1:1 2:1.....free play)
- * Difficulty(EasyStandard Hard)
- * Life (only for HOD3)(123)
- * Cartridge (only for HOD3)(1218)
- * Back



PIC 9

Game show & hidden : Enter the Game show & hidden menu (PIC 10), press 1P start button to move the cursor to choose the game you want to set, press 1P's trigger to display or hide this game. If you want to run 1 game only, hide the rest game. In this mode the machine will automatically enter this game when you turn on the machine.



PIC 10

DEMO SOUND : ON/OFF

语言/LANGUAGE : Chinese/English

SAVE & EXIT: Please move the cursor to “**SAVE & EXIT**” and press 1P’s trigger to save the setting (PIC 10) , setting didn’t finished yet, Please do not turn off the power , the machine will restart and enter the setting menu, setting finished.



PIC 11

Exit without save: If you don’t want to save the setting you made, please choose this item then press 1P’s trigger. Please do not turn off the power, the machine will restart and enter the setting menu, in this mode the setting you made just now would not work.

Remark: This Product have a function to record all the coin insert into this machine, and will show on the up left corner in the setting menu, unable to reset.

Thanks for purchasing our products !



Deluxe Cabinet

Mini Cabinet

**Thanks For Purchasing
Our Products**